

MOBILE CONTROL CENTER™




WARNING:
CHOKING HAZARD - Small parts.
Not for Children under 3 years.

CAUTION: PLEASE READ BEFORE PLAYING WITH TOY

- Do not: 1) aim toy at anyone, 2) hit anyone with toy, 3) poke anyone with toy, 4) swing toy at anyone, 5) step on toy.
- Be careful not to pinch fingers with hinged parts of toy.


CAUTION: Keep batteries away from children. Batteries may be harmful if swallowed. Requires 2 AAA batteries. Batteries not included. **NOTE:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of used batteries properly.

CONTENTS





HOW TO INSERT/REPLACE BATTERIES

Insert 2 AAA batteries making sure to line up the + and - indicators. Replace battery cover, and turn screw clockwise until secure.



HOW TO PLAY IN TRUCK MODE

- 1) Attach Cannon to position shown. (Tsunami Cycle and Glider Cycle sold separately)
- 2) Open rear hatch and insert Cycle and launcher, attach to joint as shown.
- 3) Deploy by pushing button as shown.



HOW TO PLAY IN ZORD MODE

- 1) Pull down rear Chassis as shown.
- 2) Pull down front Chassis as shown.
- 3) Lift up front part as shown.



- 1) Insert missile (A, B or C) into arm as shown.
- 2) Push button to deploy.
- 3) You can attach 2 missiles to joints to store as shown.



- 1) Pull down seat and insert Red Ranger as shown.
- 2) Lift up seat to secure.




HOW TO COMBINE ACCESSORIES WITH LAUNCHER




HOW TO PLAY IN CONTROL CENTER MODE

- 1) Lift up whole trailer to form tower.
- 2) Pull up Base, and insert missile (A, B or C) as shown. Push button to deploy.
- 3) Open rear hatch, side hatch, and runways.
- 4) Attach Claw as shown.
- 5) You can attach Red Ranger to side hatch, attach claw's arms onto Ranger's hands.



- 1) Attach launcher with accessory to joint 1 and push button to deploy down runway.
- 2) Attach Ranger with platform to joint 2. Use lever in back to move Ranger up and down.
- 3) Attach Antenna to Rear Hatch as shown.



HOW TO ATTACH LOOK-OUT BASE

- 1) Attach Red Ranger onto platform with Cannon as shown.
- 2) Attach it to one of the 2 positions, hole A for front watch mode, hole B for rear watch mode.

