



® Asst. #10810
Item #10811

RED TALKING MEGA BATTLEZED POWER RANGER™



WARNING:

CHOKING HAZARD-Small parts.
Not for Children under 3 years.


CAUTION: PLEASE READ BEFORE PLAYING WITH TOY

- **Do not:** 1) aim toy at anyone, 2) hit anyone with toy, 3) poke anyone with toy, 4) swing toy at anyone, 5) step on toy.
- **Be careful** not to pinch fingers with hinged parts of toy.

CAUTION: Keep batteries away from children. Batteries may be harmful if swallowed. Requires 2 AAA batteries. Batteries not included. **NOTE:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of used batteries properly.


HOW TO INSERT/REPLACE BATTERIES

1. Unscrew screw on battery box and remove cover as shown.
2. Insert 2 AAA batteries (not included) making sure to match the + and - indicators.
3. Replace battery cover.
4. Turn the switch to ON and you are ready to play.




HOW TO PLAY IN RANGER MODE

1. Attach helmet onto head as shown.
2. Push button on back to activate sound.




HOW TO PLAY IN MEGAZORD MODE

1. Attach each part onto body as shown.
2. Push button on back to activate sounds. (Sound differs from Ranger mode.)



HOW TO PLAY IN T-REX MODE

1. Attach each part as shown. Pull out joint for the tail to be connected.
2. Push button on back to activate sounds. (Sounds are the same for T-Rex and Ranger mode.)



Requires 3 AAA batteries. Batteries not included.

Conforms to safety standards ASTM F963-96a. Color, style and decoration may vary. Distributed by Bandai America Incorporated, 5551 Katella Avenue, Cypress, California 90630. TM & © 2003 BVS Entertainment, Inc. and BVS International N.V. Used under license by Bandai America Incorporated. TM & © ABC Inc. All Rights Reserved.