



Place the **TURBO STAR CHARGES** in the **YELLOW TURBO RANGER's** hands, as shown. Then, insert the Turbo Key into the slot on the back of the **YELLOW TURBO RANGER**. Turn the Key back and forth to make her move her arms, as shown.



WARNING:

**CHOKING HAZARD - Small parts.
Not for Children under 3 years.**

NOTE:

If you lose the Turbo Key, you can still activate your action figure by turning the key slot left and right.