

Push down on the shift lever to lift Phantom Ranger's chest plates and activate the spinning turbine in his chest. Release the lever to return the chest plates to original position and stop the spinning turbine. Armor plates on his thighs fold out to reveal the detailed inside construction.



WARNING:

**CHOKING HAZARD - Small parts.
Not for Children under 3 years.**