


To activate the light up weapon and sound on your Power Ranger, press the button on weapon, as shown.



Weapon can be placed in the Power Ranger's hand or in the holster, as shown. To attach shoes to feet, line up posts on shoes with holes on bottom of figure's feet.

