


1. Place handle in Power Ranger's right hand, as shown.
2. Insert peg on weapon into hole on figure's right shoulder.
3. Connect hose to jet pack.
4. Spin dial on back to activate weapon.
5. V-Lancer can be placed in figure's left hand.



side view

