


SABAN'S BEETLEBORGS METALLIX™

DATA BONDER INSTRUCTIONS

The numbers in the rectangles indicate the order of the instruction steps.

WARNING:
CHOKING HAZARD - Small parts.
Not for Children under 3 years.

MAIN ELEMENTS




DATA BONDER



XX INPUT CARD
(CHROMIUM GOLD BEETLEBORG)





XZ INPUT CARD
(TITANIUM SILVER BEETLEBORG)



ZZ INPUT CARD
(PLATINUM PURPLE BEETLEBORG)

HOW TO PLAY WITH THE DATA BONDER


- 1** To turn the DATA BONDER on, press the ON/OFF Switch to the on position, as shown by the arrow below. The DATA BONDER will beep four times.



- 2** After the DATA BONDER has been turned on, it will continue to beep and the light in the center of the device will flash. Press and hold the Activator Button to make all of the lights flash and to hear a special sound effect.



BATTERY INSTALLATION

Unscrew and remove the Battery Cover. Insert 2 AAA Batteries, as shown, and reattach the Battery Cover.




USE ONLY STANDARD OR ALKALINE BATTERIES. DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD OR RECHARGEABLE BATTERIES.


Insert each Input Card into the DATA BONDER, as shown below.



- 3** When you insert each Input Card into the DATA BONDER, its corresponding antenna will flip out, the lights will flash and you will hear a new sound effect.



- 4** After you have inserted an Input Card, press and hold the Activator Button to hear another sound effect. Each card activates its own unique sounds and lights.



- 5** Before you insert a new Input Card, remove the current card and fold the Antenna down, as shown above.