

Place FIREBORG's right arm at his side. Then, press in the button located on his back to make him raise the weapon and activate the light.



2 LR 44 Batteries included.

To replace the batteries, unscrew the Battery Cover and insert two LR 44 Batteries, as shown. Then, reattach the Battery Cover.



USE ONLY STANDARD OR ALKALINE BATTERIES. DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD OR RECHARGEABLE BATTERIES.